K9 HYDROBATHS

User Manual

PREVENT SKIN CONDITIONS

REDUCE BATHING TIME

RELIEVE TIRED MUSCLES



K9 MOBILE GROOMING SUPPLIES

K9 Standard Hydrobath

Installation

We recommend that your bath is installed by a competent person.

Water Supply

The Standard K9 Hydrobath requires a hot and cold water supply via a mixer tap. This can be permanently connected to the sump or water can be directed by a flexible hose.

Waste

Water is emptied from the sump by opening the waste valve and directing it as required to a suitable drain. The bath must be higher than the drain to create a fall and avoid dirty water being trapped in the pipework. The waste valve has a 40mm threaded adaptor, which can be connected to 40mm solvent weld pipe (standard bath waste pipe).

Operation

1. Check the temperature of the water and fill the sump to approximately 80-90%.
2. A small amount of low lather shampoo should be dispensed into the sump.
3. The pump is operated by the switch on the front of the bath. Do not switch the pump on and off repeatedly in a short space of time otherwise the capacitor in the pump will fail.
4. Wash the dog as appropriate for as long as necessary – remember you are only recycling the water in the sump.
5. Empty the dirty water by opening the waste valve. Close the valve and refill with clean water (see note 1), and repeat the process to rinse the dog.
6. The shampoo and rinsing processes can be repeated as many times as is necessary.

Maintenance

1. Wash down your bath with warm soapy water at the end of each day's use. Do not use abrasive cleaning materials on your fibreglass bath. Specialist acrylic or plastic cleaners may be used with care.
2. If you put a baby steralising tablet in the waste at the end of the day, it will keep the bath smelling fresh.
3. Check your heating element and shower head every 2 or 3 months for a build up of limescale, especially if you live in a hard water area. If limescale completely encloses the element, it will reduce performance and may eventually fail. Use a proprietary limescale remover as necessary and flush the system with clean water before recommencing grooming.
4. It is essential that the inlet filter is in working order to avoid dog hairs getting into the pump, and we also recommend that you use a sink strainer to minimise the amount of hair and debris entering the waste system.

FAQ's

Why is my pump not working?

It may be an airlock - fill the sump to the top and switch the pump on, then switch it off and wait for bubbles to appear. Repeat as necessary.
If you hear the pump trying to work, it may be the capacitor or the pump may be jammed with dog hair.
If you cannot hear any noise, turn off the power and check the electrical connections, plugs and switch.

Why is the waste water not emptying?

Check that the ball valve is operating and not clogged with dog hair.
Check the drainage point is lower than the bath.

Why is my bath is leaking?

If the leak is coming from any of the plumbing, this can usually be remedied by tightening the connection or by replacing the defective part.
In the unlikely event that the leak is coming from the bath or tank, please call 01323 743666 for assistance.

Warranty

Warranty

The company will repair or replace any defective products, which result from faulty materials and/or workmanship, provided such faults are notified in writing within 12 months of delivery. The company' liability is limited to the cost of repair or replacement, and the company shall, under no circumstances accept any liability for consequential loss, damage to other property or personal injury. Any products returned under warranty, which are subsequently found to be working normally, will incur delivery and handling charges.

Delivery

When products are delivered, the customer is responsible for checking they are in good working order. Failure to do so may result in additional charges if products are returned to the Company.

Cancellation

There is no charge for the cancellation of orders for standard products prior to delivery. Non standard products will be charged at cost for the work done.

Your Warranty

Customer Name .....

Customer No .....

Hydrobath Model .....

Date of Purchase .....

Warranty Expires .....